

Packlist 20W solarpanel + mounting

1. Bracket left and right
2. Solarpanel 20 W incl. cable
3. Screw package
 - 3.1. 4x lock nut M6
 - 3.2. 8x washer 6,4x12x1,6
 - 3.3. 4x bolt M6x16
 - 3.4. 4x screw M5,5x13
 - 3.5. 4x sheet metal nuts M5,5
 - 3.6. 1x clamp 8x15
 - 3.7. 1x cable tie 150mm



Assembly instructions

1. fasten bracket with SK screws M6x16
2. lock in the switch cabinet with SK lock nuts M6
3. use washers 6.4x12x1.6 on both sides
4. secure the cable at the rear with a clamp and cable tie
5. fasten the solar panel with M5.5 sheet metal nuts and self-tapping screws M5.5x13

